

Inflation Guidelines

- Performing a daily quality control air pressure test on one package from each air machine using a TR air gauge.
- Cleaning wheels and checking for any damage.
- Installing proper valve cores and valve caps.

Safety

- Ensure no items (valve cores, tools, etc.) sit on top of the protective cage.
- Wearing **eye and ear** protection while blasting the cheetah

Pressure Settings

- Airing to specified maximum 50 psi to seat beads
(Only supervisor is allowed to override 50 psi to seat bead.)
- Airing every package to a final **36 psi**
- Air load range D and E to **cold set pressure on sidewall.**
- Air load range F and G to no more than **80 PSI**

***DO NOT INFLATE BEYOND RECOMMENDED COLD PRESSURE
NOTED ON SIDEWALL***