



IMMEDIATE ACTION LEADERSHIP

COMPRESSORS

September 21, 2016

What and Why

Based on recent information concerning compressors, it is necessary to send this updated Immediate Action Message. **NOW ALL Schrader and Chicago Pneumatic compressors within each region must be checked for cracks and air leaks.**

Expectation

Safety Leader/Store Manager:

- The stores' Safety Leaders will check for air leaks in the tanks.
- If an air leak is identified in a tank, the Safety Leader will immediately notify Regional Maintenance.
 - Regional Maintenance will remove the tank from service

Warehouse Adjustment Manager or Maintenance Manager:

- Perform a visual inspection of each Schrader and/or Chicago Pneumatic compressor.
- Complete iAuditor.

**A list of stores with Schrader and/or Chicago Pneumatic compressors is attached.*

Final Step

A status update issued to Senior Operations 24 hours after IAM submission to be followed by weekly updates.

Thank you for keeping our people Safe!



AZP

AZP 17
AZP 22
AZP 29
AZP 33
AZP 34
AZP 46
AZP 47
AZP 48
AZP 55
AZP 56
AZY 02

CAL

CAL 16
CAL 42

CAN

CAN 02
CAN 03
CAN 04
CAN 05
CAN 07
CAN 14
CAN 16
CAN 17
CAN 18
CAN 21
CAN 22
CAN 23
CAN 24
CAN 26
CAN 29
CAN 30
CAN 32
CAN 33
CAN 38
CAN 42
CAN 43
CAN 45
CAN 46
CAN 47

CAS

CAS 01
CAS 07
CAS 08
CAS 09
CAS 13
CAS 23

CAS 25
CAS 27
CAS 35
CAS 36
CAS 48

COD

COD 09
COD 19
COD 24
COD 28
COG 02
CON 03
COS 03
COW 01

FLO

FLD 01
FLG 03
FLJ 09
FLO 02
FLO 06
FLO 10
FLP 01
FLT 02

GAA

GAA 06
GAA 28
GAA 29
GAA 30

KSK

IAC 01
IAD 01
IAN 01
IAQ 01
IAQ 02
KSK 01
KSL 01
KSW 01
KYB 01
KYL 01
KYL 02
MOK 01
MOK 02
MOK 03
MOK 05
MOK 06
NEO 01
NEO 03

NEO 04

NEO 05

NEO 06

UTS

IDB 01

IDB 02

IDB 03

IDB 04

ILC

ILC 02

ILC 04

ILC 08

ILC 12

ILC 15

ILC 22

ILC 24

ILC 30

ILC 31

ILC 32

ILC 33

ILC 34

ILR 01

ILR 02

INI

INE 02

INF 03

INI 14

OHC 10

OHD 03

MIW

MIG 23

MIA

MID 04

MID 18

MID 26

MIA 02

OHN 01

OHN 02

OHN 03

MNM

MNM 07

MNM 28

MNM 29

TNN

MSN 01

TNM 01

TNN 13

TNN 15

NCC

NCC 17

SCC 07

SCC 10

SCC 11

NMA

NMA 04

TXE 02

TXE 06

TXL 01

TXO 01

NVL

NVL 01

NVL 05

NVL 10

NVL 13

NVL 15

NVR 05

OKT

ARO 01

MOO 01

OKO 03

OKO 10

OKO 11

OKO 12

OKT 03

TXD

TXD 06

TXD 18

TXD 22

TXD 34

TXD 42

TXD 47

TXD 62

TXD 76

TXD 77

TXD 78

TXD 79

TXD 80

TXH

TXH 11

TXH 23

TXH 34

TXH 37

TXH 41

TXH 81

TXH 82

TXH 85

TXS

TXA 18

TXA 19

TXA 20

TXA 21

TXC 03

TXC 04

TXC 06

TXC 11

TXC 13

TXC 14

TXC 15

TXS 08

TXS 16

TXS 22

TXS 24

TXW 06

TXW 07

TXW 08

WAS

WAS 17

WAS 19

WAS 24

WAS 27

WIA 01

ORP 09

ORP 10

MTM 01

DTD

WDOH01