

Schrader Compressor

September 6, 2016

What and Why

- All Schrader compressors within each region must be identified and accounted for by store number and then inspected due to a potential hazard.
- The stores' Safety Leaders will collect the manufacturer names and serial numbers.
- You will receive the list of Schrader compressor serial numbers and their respective store numbers (specific to your region) from the Technical Team at Corporate.

Action

Warehouse Adjustment Manager or Maintenance Manager:

- Confirm the number of "Schrader" manufactured compressors in the region along with their serial numbers.
 - If the serial number is incorrect – enter the correct serial number in iAuditor during the "Final Step."
- Perform a visual inspection of each Schrader compressor.
 - You will receive written inspection procedures through iAuditor
 - If a compressor is found to be defective, follow the Lock out/Tag out procedures (attached: Document 58466, Published 3/29/16, ver. 1.0).
- If the Lock out/Tag out devices are not available:
 - Use any lock on the electrical box
 - Cut the power cord on the auto-drain
 - Use heavy duty tape to ensure the ball valve remains closed from the system

Final Step

Please be sure you have the latest version of iAuditor downloaded for Compressor Inspection Procedures!

Thank you for keeping our people Safe!